

A novel Method for Bacterial inactivation Using Engineered Water Nanostructures (EWNS)

G. Pyrgiotakis, J. McDevitt, J. Brain, P. Demokritou



Center for Nanotechnology and Nanotoxicology at
Harvard School of Public Health

<http://hsph.harvard.edu/nano>

Background

- Airborne pathogens constitute a major burden of disease
- Bacterial infection through fomites is an equally important health risk especially in hospitals and food industry
- Nanotechnology based methods are emerging as intervention technologies for antimicrobial inactivation.
 - Ag nanoparticles (ROS generation via Ag⁺ ions)
 - TiO₂ nanoparticles (ROS via UV/VIS irradiation)
- Limited only on surfaces – toxic when airborne



Ideal disinfectant...


- Effective and efficient
- Stay airborne from long enough to inactivate bacteria
- Non – toxic to humans
- Leave no chemical trace – green
- Inexpensive

Potential Solution

Engineered Water NanoStructures (EWNS)




Concept: Engineered Water NanoStructures (EWNS)




Physicochemical Characterization

PCM characterization – Surface charge



- On average the EWNS have 10 electrons per structure.
- The surface charge increases the surface tension that retards the evaporation.
- The droplets evaporate until the droplet reaches a terminal radius.
- A theoretical model developed by Nielsen that allows to estimate the terminal diameter
- **PITFALL:** Electric charge can implicate the size measurement as commonly used instruments rely on particle charge neutralization.




Size: AFM measurement (1/2)



Polydispersity due to the Rayleigh effect




Size: Size distribution (2/2)



- The mean EWNS diameter is 25 nm (AFM measurement)
- SMPS, charge adjusted mean diameter was found 19 nm





Lifetime (1/1)



The EWNDs are very stable and there is no noticeable evaporation for almost an hour.



PCM Characterization – ROS detection using ESR



The EWNS are loaded with both O_2^\bullet and OH^\bullet .




Antimicrobial properties Applications


Surface Inactivation

Surface bacteria inactivation - Methods


- Three type of bacteria (gram negative, gram positive, mycobacterium & spores)
- Surface: Stainless steel
- Controls: Air, ions
- Dose at 9000 #/cc (trhee time points, 30 min, 60 min, 90 min)




Surface inactivation – Results (1/2)




Serratia Marcescens



Staphylococcus Aureus



Mycob. parafortuitum





Bacillus Subtillis

- The structures were effective in inactivating the bacteria with the gram negative to be more susceptible than the gram positive.
- Mycobacterium has one log reduction (at higher dose)
- Spores, the ultimate survivors, under the same conditions were not effective at all.



Surface inactivation – Results (2/2)




- After 90 minute exposure (TEM pic on the right)
- Destruction of the cell-wall
- The dead bacteria lost its shape and have developed a large vacuole



Antimicrobial properties Applications

Air Inactivation


Air Disinfection - Methods




- Generate a bioaerosol of known concentration and mix it with a EWNS aerosol of controlled number of EWNS.
- Monitor the concentration of the bioaerosol as a function of time.
- Two exchange rate scenarios 2.9 ACH and 1.7 ACH




Air Disinfection - Methods



Air Disinfection - Methods




Air Disinfection – Results (1/4)



2.9 ACH: $R_b = \text{EWNS} / \text{Bacteria} = 7.9 \cdot 10^6 \text{ EWNS} / \text{cfu}$



Air Disinfection – Results (2/4)



1.7 ACH: $R_b = 3.3 \times 10^6$ EWNS/cfu



Air Disinfection – Results (3/4)

- Environmental chamber conditions

- $R_b = 8.7 \times 10^6$ EWNS/cfu
- 3.0 ACH, res. Time = 19.5 mins


- RH: 40%

- T: 25 °C

- Ozone 110.25 ± 11.78 ppbv

- The EWNS can hinder the growth of bacteria (50% less CFU with the EWNS)

- Can completely remove the bacteria in ~30 mins.




Air Disinfection – Results (4/4)

- Environmental chamber conditions

- $R_b = 3.3 \times 10^6$ EWNS/cfu
- 1.7 ACH, res. Time = 35 mins
- RH: 47%
- T: 25 °C
- Ozone 148.54 ± 15.56 ppbv

- The EWNS can hinder the growth of bacteria (~40% less CFU with the EWNS)
- Can completely remove the bacteria in ~ 30 mins and faster than scenario 1.



Toxicological Characterization


using a rodent model

Toxicological characterization - Methods Study design


- Exposure system - Full body inhalation chambers
- 3 Groups of 6 mice (2 control, 4 exposed) for each dose
- 3 doses: 10,000 (surface inactivation), 40,000 p/cm³ (air inactivation) and 60,000 p/cm³
- 24 hours endpoint
- Bronchoalveolar lavage (BAL) and nasal lavage (NL) will be performed (obligatory nose breathers).
- Look for inflammation biomarkers:
 - Lactate dehydrogenase (LDH) – BAL/NL
 - Myeloperoxidase (MPO) – BAL
 - Albumin – BAL
 - Neutrophils – BAL
- Breathing patterns




Toxicological characterization - Methods



Toxicological characterization - Methods




Toxicological characterization – Results (1/3)



Very steady particle flow over a long periods of time. ~13,000 ,42,000 and 60,000 #/cc with 10, 25 and 35 ppbv of ozone respectively.





Toxicological characterization – Results (2/3)



No statistically significant inflammation responses.



Toxicological characterization – Results (3/3)



No significant change in the breathing pattern



Summary

- The Sustainable, green technology, chemical free using water with a great potential to revolutionize the pathogen disinfection
- Unique PCM properties:
 - 10 electrons per structure
 - loaded with OH^\bullet and O_2^\bullet radicals.
- Effective in air and on surfaces
- The toxicological evaluation showed that there is no effect at the concentrations that are effective for the surface and air inactivation.

Future Work

- Explore other applications:
 - Open wound – wound healing
 - Fresh produce disinfection
 - Air disinfection – airborne transmitted diseases (TB), flu



Acknowledgements

Dr. R. Molina, Research Scientist
Center for Nanotechnology and Nanotoxicology
Harvard School of Public Health

Dr. E Diaz, Research Scientist
Center for Nanotechnology and Nanotoxicology
Harvard School of Public Health

Dr. T. Yamauchi, Research Director
Research & Development Center
Panasonic Electric Works Co., Ltd

Y. Kubo, Research Director
Indoor Air Quality Appliances Division
Panasonic Ecology Systems Co., Ltd

Dr. Y. Mitsuyama, Optical Engineering Manager
Panasonic Boston Lab
Panasonic USA, Ltd

T. Lee, Engineer
Panasonic Boston Lab
Panasonic USA, Ltd

Dr. S. Leonard, Research Scientist
NIOSH
Center for Disease Control

Panasonic Delegates:

T. Imai, Engineer
Home Appliances Manufacturing Unit
Panasonic Electric Works Co., Ltd

H. Hirasawa, Senior Coordinator
Corporate R&D Division
Panasonic Ecology Systems Co., Ltd

Students:

A. Bordini
Medical School
University of Sao Paulo, Brazil

D. Hunt, Y. Gao (Grace)
Department of Biology
Northeastern University



Trust Science Innovation

Loaning an electrometer

Partially Funded by:

Panasonic



**Center for Nanotechnology and Nanotoxicology
at Harvard School of Public Health**

Thank You!

